CABINET PARTS

For Model: LEB6200PQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LEB6200PQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8535829	Installation Instructions
	8533770	Sheet, Cycle Feature
	8522243	Use & Care Guide
	8528187	Wiring Diagram
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Washer Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3403630	Plug, Strike Hole
7	3396805	Panel, Rear
10	3406109	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3404413	Plug, Hinge Hole
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21	3403444	Panel, Front
23	685203	Clip, Felt Pad (3)
24	690081	Catch, Door Assembly
27	342055	Screw, 8−18 x 1/2
28	3405514	Hinge, Door
33	3403431	Strike, Door
35	3402341	Door, Rear
36	3402335	Door, Front
37	3405184	Handle, Door
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	3393008	Screw, 10−16 x 1/2
41	3397659	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3394341	Pulley, 60 Hz.
62	8538262	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3405246	Seal, Door
68	697776	Screw, 10−32 x 5/8 (External Ground)

TOP AND CONSOLE PARTS

For Model: LEB6200PQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LEB6200PQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2	694419	Buzzer, Mini
4	8271365	Cap, End (L.H.)
6	388326	Screw, Console
7	693995	Screw, Hex Head
8	8271359	Cap, End (R.H.)
9	3395683	Housing, Connector (Motor)
10	8557857	Screen, Lint
11	8536939	Clip, Spring
13	688983	Screw, 8−18 x 5/8
14	3400859	Screw, Grounding
16	8557930	Top
18	94614	Terminal
19	8539888	Wire, Jumper (PTS to Buzzer)
21	8299778	Timer, 60 Hz.
23	3394427	Clip, Harness
26	8544935	Knob, Control
29	3390646	Screw, 8−18 x 5/16
30	357213	Nut, Push−In (2)
31	8299867	Harness, Wiring
32	3404233	Switch, Push−To−Start
33	8544955	Timer Knob Assembly
34	3936144	Connector
35	8271418	Bracket, Control
36	8545973	Panel, Control

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION

ACCESSORY PARTS

279948	Kit, Dryer Repair
3404351	Dry Rack
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH−UP (1/2oz.)

72017	White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)

BULKHEAD PARTS

For Model: LEB6200PQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal−Bias
9	3977393	Thermal Cut−Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	8557384	Housing, Blower
12	8066155	Clip
13	343641	Screw, 10−16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
17	3403585	Element, Heater
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
22	3394196	Seal, Blower
24	8066086	Drum Hole Plug
25	3390647	Screw, 8−18 x 1/2
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3403491	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11−16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST